




DESCRIPTION

The control monitor connects to a heavy duty Sculcon® junction box with attached cable and special quick release snap-on plug. The Scully Ground Plug connects to a specially designed electronic Scully Ground Ball mounted on each vehicle. The controller in conjunction with the ground ball provides and verifies vehicle grounding before loading can begin. The controller must receive an electronic return signal from the ground ball throughout the loading operation.



*Sculcon Junction Box
with Ground Plug & Cable*



ORDERING INFORMATION

Description	Part Number
SC-47 Sculcon Junction Box, Ground Plug, Blk Straight Cable, 20'	08249
Replacement Plug and 20' Straight Cable Assembly for SC-47 Sculcon Junction Box	08219
SC-47 Sculcon Junction Box, Ground Plug, Blk Coil Cable, 32'	08567
Replacement Plug and 32' Coiled Cable Assembly for SC-47 Sculcon Junction Box	08566
Replacement Plug only	08565
SC-47 Sculcon Box Assy, General Purpose	32319
Strain Relief, 3/8" for Grounding Cable	32445

00000 Rev A
January 2017



Scully Signal Company
70 Industrial Way
Wilmington, MA 01887, USA
800 272 8559 • sales@scully.com

Scully Systems Europe NV
Maanstraat 25
2800 Mechelen, Belgium
+32 (0) 15 56 00 70 • info@scully.be

Scully UK Ltd
Meridian House, Unit 33
37 Road One Winsford Industrial Estate,
Winsford Cheshire CW7 3QG, UK
+44 (0) 1606 553805 • sales@scullyuk.com

